



18-19 Rocker switch panel install

Tools needed;

1) 4mm Allen wrench

2) Pick or flat screwdriver

Step 1: Use a screwdriver or a pick to pull the floor of the tray out. The tray has four tabs two in the back and two in the front. The tray removal allows you to route your wiring without having to drill or cut any holes.





Step 2: Tray is out, run all you wires, leave some extra, leave the center switch out, but keep your wires hooked up. Insert the supplied mounting bracket into the upper hole then let it rest in place.





Step 3: With all switches in place except the center, set the panel into position, using one finger, place it into the open hole and guide the mounting bracket into alignment with the hole on the panel. Use the provided hardware to screw through panel and into the panel.





Step 4: Once the bolt is started then tighten it down. You can also try to attach the mounting bracket to the panel first and then set the bracket into place, you will still need to leave a switch of your choice out so you can use a finger to guide the mount into position. That's the final installation, do not throw away your floor plate for the console, if you ever sell the car you can reinstall it back to factory.

